
WANDERER

CLASS RULES

2019



The Wanderer was designed in 1981 by Ian Proctor.

INDEX

D.1 Parts	12
D.2 General	12
D.3 Hull Shell	13
D.4 Deck	13
D.5 Buoyancy Tanks	14
D.6 Gunwale and Rubbing Strakes	14
D.7 Bulkheads	
D.8 Thwarts and Benches	14
D.9 Assembled Hull	15
Section E – Hull Appendages	18
E.1 Parts	
E.2 General	18
E.3 Centreboard	18
E.4 Rudder Blade, Rudder Stock and	
Tiller	19
Section F – Rig	19
F.1 Parts	
F.2 General	20
F.3 Mast	20
F.4 Boom	21
F.5 Spinnaker Pole and/or Whisker P	ole 21
F.6 Standing Rigging	22
F.7 Running Rigging	22
Section G – Sails	22
G.1 Parts	22
G.2 General	23
G.3 Main sail	23
G.4 Head sail	24
G.5 Spinnaker	25
PART III – APPENDICES	
Section H – Appendix 1	
H.1 BUOYANCY TESTS	
Change History	28
	D.2 General

INTRODUCTION

The intention of the Class Rules is to define the design characteristics to ensure that boats are as alike as possible in all aspects affecting speed and handling so that racing is a true test of sailing skill. The boat's characteristics of safety, constructional strength, ease of maintenance and moderate cost shall be maintained.

Wanderer hulls, hull appendages, rigs and sails are measurement and manufacturing controlled.

Wanderer hulls and hull appendages shall only be manufactured by a builder licensed by the copyright holder – in the class rules referred to as licensed builder.

Equipment is required to comply with the Wanderer Building Specification and official drawings.

Wanderer sails have no restriction on manufacturer.

Wanderer hulls, hull appendages, rigs and sails may, after having left the manufacturer, only be altered to the extent permitted in Section C of the class rules.

Rules regulating the use of equipment during a race are contained in Section C of these class rules, in The Equipment Rules of Sailing (ERS) Part I and in the Racing Rules of Sailing (RRS).

This introduction only provides an informal background and the Wanderer Class Rules proper begin on the next page.

The class permits In House Certification (IHC) for section G – Sails.

NOTE: THESE RULES APPLY TO THE BOAT WHEN IT IS RACING.

PLEASE REMEMBER: IF THESE RULES DO NOT SAY THAT YOU CAN – THEN YOU CAN NOT.

PART I – ADMINISTRATION

Section A – General

A.1 LANGUAGE AND ISAF RULES

- A.1.1 The official language of the class is English and in case of dispute over translation the English text shall prevail.
- A.1.2 The word "shall" is mandatory and the word "may" is permissive.
- A.1.3 These **class rules** shall be read in conjunction with the ERS.
- A.1.4 Except where used in headings, when a term is printed in "**bold**" the definition in the ERS applies and when a term is printed in "*italics*" the definition in the RRS applies.

A.2 ABBREVIATIONS

- A.2.1 ISAF International Sailing Federation
 - MNA ISAF Member National Authority
 - ICA International Class Association
 - NCA National Class Association: Wanderer Class Owners' Association UK
 - ERS Equipment Rules of Sailing
 - RRS Racing Rules of Sailing
 - WTC Wanderer Technical Committee
 - IHC In House Certification

A.3 AUTHORITIES

- A.3.1 The Class Authority, and the **Class Rules** Authority of the class is the NCA which shall co-operate with the Copyright Holder in all matters concerning these **class rules**
- A.3.2 Notwithstanding anything contained herein, the NCA has the authority to withdraw a **certificate**
- A.3.3 The official drawings and specifications are made and the class rules are enforced (or their enforcement may be waived) without responsibility on the part of any member of the NCA or the designer of the Wanderer, or the copyright holder for the time being of the Wanderer design, for any injury, loss or damage howsoever caused.
- A.3.4 The **certification authority** of the class is the licensed builder.

A.4 ADMINISTRATION OF THE CLASS

- A.4.1 The administrative functions of the class shall be carried out by the NCA.
- A.4.2 In countries where there is no NCA, the administrative functions as stated in these **class rules** shall be carried out by the UKNCA.

A.5 CLASS RULES VARIATIONS

A.5.1 At Class Events – see RRS 89.1.d), RRS 87 applies.

A.6 CLASS RULES AMENDMENTS

A.6.1 Amendments to these **class rules** shall be carried out according to the constitution of the NCA. All amendments are subject to the approval of the Copyright Holder or Representatives nominated by him.

A.7 CLASS RULES INTERPRETATION

- A.7.1 The **class rules** are complementary to the official drawings, specifications and Builders Certificate. Interpretation in any way of **class rules** and drawings etc shall be made by the WTC who may consult the NCA. All interpretations are subject to the approval of the Copyright Holder or Representatives nominated by him.
- A.7.2 The NCA is empowered to grant dispensation in exceptional cases where this is considered to be in the interests of the class. Any such dispensation shall be recorded on Builders Certificate of the boat concerned and shall be reported to the NCA which shall confirm or cancel the dispensation within six months of the report having been received.

A.8 RULE COMPLIANCE CHECKS

- A.8.1 Any boat with a Builder's certificate shall be liable to a measurement check at the discretion of the WTC or NCA but only by an **official measurer.**
- A.8.2 An **official measurer** approved by the NCA may periodically visit each licensed Builder in order to make random measurements of boats to verify whether they comply in all respects with the Class Rules, specifications and official plans. The cost of the Measurer's services shall be met by the NCA.
- A8.3 If an **official measurer** is in any doubt as to the application of, or compliance with, the **class rules** he shall consult the NCA which shall give a ruling.

A.9 SAIL NUMBERS

A.9.1 Sail numbers shall be issued by the licensed Builder.

A.10 BUILDER'S CERTIFICATE

- A.10.1 The Builders **certificate** shall record the following information:
 - (a) Class
 - (b) **Certification Authority** The licensed Builder
 - (c) Sail number
 - (d) Owner's name and address
 - (e) EU Craft identification number
 - (f) Builder/Manufacturers details
 - (g) Date of issue of initial certificate.
 - (h) Date of issue of certificate
 - (i) Hull weight
 - (i) Number and weight of correctors
 - (k) Date of completion of Buoyancy air test

The Builder shall be responsible for the completion and forwarding of the Builder's Certificate and the issue and fixing of the building plaque as required

- by Rule A.10.2 and D.2.5.
- A.10.2 No boat shall be deemed a Wanderer Class dinghy until one copy of the Builder's Certificate has been passed by the Builder to the owner, and a building plaque has been fastened in a conspicuous place on the hull of the boat. One copy of the Builder's Certificate shall be retained by the Builder, one by the copyright holder, and one copy sent to the NCA membership secretary.
- A.10.3 Upon receipt of a satisfactorily completed Builder's Certificate, the NCA shall enter the boat on the Register of Boats maintained by the NCA. On notification of a change of ownership, the NCA shall amend the register without charge.

A.11 VALIDITY OF CERTIFICATE

- A.11.1 The continuing validity of a Builder's Certificate shall be the responsibility of the owner.
- A.11.2 A Builder's **certificate** may become invalidated by repairs or replacements to items covered by the Class Rules, official plans or specifications. The boat may then be measured in respect of the affected items by an **official measurer**, and the Builder's Certificate endorsed accordingly

A.12 RE-CERTIFICATION

A.12.1 If a Builder's certificate is lost a replacement may be available through the NCA

Section B – Boat Eligibility

For a **boat** to be eligible for *racing*, it shall comply with the rules in this section.

B.1 CLASS RULES AND CERTIFICATION

- B.1.1 The boat shall:
 - (a) be in compliance with the **class rules**.
 - (b) have a valid Builders **certificate**.
 - (c) have valid **certification marks** as required

B.2 FLOTATION CHECKS

- B.2.1 The owner is responsible for ensuring the boat satisfactorily complies with the floatation tests in Appendix H
- B.2.2 A race committee may require that a **boat** shall pass a flotation test in accordance with Appendix H.

B.3 CLASS MEMBERSHIP

B.3.1 At least one member of the crew of the boat shall be a Full, Honorary or Associate member of the NCA when competing in the National or Inland Championship events.

PART II – REQUIREMENTS AND LIMITATIONS

The **crew** and the **boat** shall comply with the rules in Part II when *racing*. In case of conflict Section C shall prevail.

The rules in Part II are **closed class rules**. **Certification control** and **equipment inspection** shall be carried out in accordance with the ERS except where varied in this Part.

Section C – Conditions for Racing

C.1 GENERAL

C.1.1 RULES

The ERS Part I – Use of Equipment shall apply.

C.2 CREW

C.2.1 LIMITATIONS

The **crew** shall consist of at least 2 persons except during specific single handed events.

C.3 PERSONAL EQUIPMENT

C.3.1 MANDATORY

The boat shall be equipped with **personal buoyancy** for each crew member to the minimum standard ISO 12402:5 (CE 50 Newtons).

C.4 ADVERTISING

C.4.1 LIMITATIONS

Advertising shall only be displayed in accordance the ISAF Advertising Code. (See ISAF Regulation 20). Advertising chosen by the owner or person in charge is not permitted.

C.5 PORTABLE EQUIPMENT

C.5.1 FOR USE

OPTIONAL

- (1) Electronic or mechanical timing devices
- (2) Magnetic or electronic compass to show heading only.
- (3) An anchor need be carried only when prescribed in the Notice of Race and Sailing Instructions.
- (4) Hand bailers and/or buckets
- (5) Water bottles or similar and their holders.

C.5.2 NOT FOR USE

OPTIONAL

- (1) Electronic navigation devices
- (2) One outboard engine
- (3) Towing Rope

- (4) Mooring rope
- (5) Paddles
- (6) Oars and rowlocks
- (7) "Bosun's box" for minor repairs
- (8) Mobile phone
- (9) Hand held VHF
- (10) Safety equipment such as flares

C.6 BOAT

C.6.1 WEIGHT

minimum maximum

The weight of the **hull** (this includes all fixed fittings)

in dry condition including centreboard and pivot pin,

floorboards fixed with clamps or turnbuckles. It may

include toe straps with fittings......136 kg

The weight shall be taken excluding **sails** and all portable equipment as listed in C.5 and any additional keelband and for the HB the removable side benches and stern locker.

C.6.2 **Corrector Weights**

- (a) **Corrector weights** of lead shall be permanently fastened to the underside of the centre thwart when the **hull** weight is less than the minimum requirement.
- (b) The total weight of such **corrector weights** shall not exceed 5 kg. See also rules A.10.1 and B.1.1.

C.7 HULL

C.7.1 MODIFICATIONS, MAINTENANCE AND REPAIR

Routine maintenance such as polishing and the repair of minor scratches and abrasions is permitted without re-measurement and re-certification.

C.7.2 FITTINGS

USE

- (1) Hand hole covers, hatches and drainage plugs shall be kept in place at all times.
- (2) Additional keelband may be fitted but it shall not be included in the **hull** weight.
- (3) HB <u>ONLY:</u> The side benches may be removed when racing.
- (4) Righting lines may be fitted.
- (5) For the HB <u>ONLY</u>, the stern locker may be removed when racing.
- (6) A spinnaker sheet/guy hook may be fitted at the stem. Maximum projection 200mm.
- (7) Cleats or eyes for the fastening of covers or lifelines may be fitted. They shall not project forward of the stem band or beyond the gunwale.
- (8) Name plates may be fitted.
- (9) An outboard motor pad may be fitted

- (10) A maximum of 2 rowlock sockets may be fitted on the aft face of the transom of deck overlap for a steering oar. (For side rowlock fittings see D.9.2).
- (11) Esprit and HB <u>ONLY</u> may have transom flaps to close self draining apertures.
- (12) Holes for fastenings used to attach fittings shall be a maximum of 10mm diameter. They shall be sealed to maintain the water-tightness of buoyancy compartments.
- (13) Stowage/tidy bags may be fitted.

C.7.3 LIMITATIONS

TOESTRAPS

- (1) Not more than 1 per side for helm and 1 per side for crew.
- (2) Forward end to be fixed to the forward face of the centreboard case and aft end to be fixed to the central spine or aft bulkhead a maximum of 320 mm from the vertical centreline to include all the strap and fitting.
- (3) They shall not be fixed to any other point except the thwart. Shockcord may be used to hold the straps outwards
- (4) Upper edge of toestrap end fittings to floor maximum 80mm.
- (5) Toestrap length may be adjustable and include fittings and cleats as necessary.

C.8 HULL APPENDAGES

C.8.1 MODIFICATIONS, MAINTENANCE AND REPAIR

Routine maintenance such as painting and polishing and the repair of minor scratches, abrasions and edge damage is permitted without remeasurement and re-certification.

C.8.2 LIMITATIONS

- (a) Only one **centreboard** and one **rudder** blade shall be used during an event of less than 5 consecutive days, except when lost or damaged beyond repair.
- (b) Steel or ballasted centreboards may be used.

C.8.3 CENTREBOARD

DIMENSIONS

C.8.4 RUDDER

USE

(1) The rudder shall be fixed to the transom using fittings which prevent the rudder coming away from the boat in the event of a capsize.

C.9 RIG

C.9.1 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) Routine maintenance such as cleaning and polishing and the replacement of defective fittings is permitted without re-measurement and recertification.
- (b) Slab reefing may be fitted and used for racing.

C.9.2 LIMITATIONS

Only one set of **spars** and standing **rigging** shall be used during an event of less than 5 consecutive days, except when an item has been lost or damaged beyond repair.

C.9.3 MAST

(a) DIMENSIONS

minimum maximum

Aft side of the **spar** to aft face of the forward bulkhead at the level of the upper surface of the wood floor (except Esprit & HB)

of the wood floor (except Esprit & HB)... 220 mm

- (b) USE
 - (1) The **spar** shall be stepped in the mast step in such a way that the heel is not capable of moving more than 5 mm.
 - (2) The mast pivot pin shall be removed when racing.
 - (3) Only un-tapered chocks shall be used to control the mast position at deck level.
 - (4) For the Esprit and the HB the aft edge of the **spar** shall not be further aft than the aft edge of the kingposts or tabernacle.

C.9.4 BOOM

(a) DIMENSIONS

minimum maximum

- (b) USE
 - (1) The intersection of the aft edge of the mast **spar** and the top of the boom **spar**, each extended as necessary, shall not be below the upper edge of the mast **lower limit mark** when the boom **spar** is at 90° to the mast **spar**.
 - (2) The boom may have spinnaker pole stowage fittings

C.9.5 SPINNAKER POLE AND WHISKER POLE

USE

- (1) The spinnaker and whisker poles may not be launched by mechanical means.
- (2) Both a spinnaker pole and whisker pole may be carried and used, but not simultaneously.

A temporary dispensation is given for the use of twin mechanically launched spinnaker poles

C.9.6 STANDING RIGGING

(a) DIMENSIONS

minimum maximum

Extended line of jib luff at deck from:

Forward end of **hull** mm 110 mm Centreline of **hull** 10 mm

(b) USE

- (1) Rigging links and rigging screws shall not be adjusted.
- (2) The forestay shall be capable of supporting the mast at all times.
- (3) A jib furler or reefing system may be fitted and may be used while racing.

C.9.7 RUNNING RIGGING

USE

- (1) The mainsail sheet may be led to a fixed point but shall not be more than a single purchase tackle between the boom and the hull at any point forward of the transom.
- (2) The mainsheet traveller or bridle controls may be led forward.
- (3) The headsail sheet may be led through ratchet blocks but they shall meet the same rules as the fairleads in D.9.
- (4) The spinnaker pole topping lift may be led aft to the centreboard case or thwart.
- (5) The spinnaker halyard shall not include any pump action or multipurchase device.
- (6) The block and tackle kicking strap of maximum purchase 16:1 may be cleated on the lower block or may be led aft to a fixed point or points on the centre thwart. The lower blocks shall be attached to the mast or to the kingposts (e.g. HB racing version).
- (7) The mainsail clew outhaul may be led aft to a fixed point or points on the centre thwart.
- (8) The mainsail Cunningham control may be led aft to a fixed point or points on the centre thwart.
- (9) The use of shockcord is unrestricted.
- (10) A gybing strop may be fitted to the boom.

C.10 SAILS

C.10.1 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) **Sails** shall not be altered in any way except as permitted by these **class rules**.
- (b) Routine maintenance such as cleaning and minor repairs not involving a full panel is permitted without re-measurement and re-**certification**.

C.10.2 LIMITATIONS

- (a) Not more than 1 mainsail, 1 jib and 1 spinnaker shall be carried aboard.
- (b) Not more than 2 mainsails, 2 jibs and 2 spinnakers shall be used during an event of less than 5 consecutive days, except when a **sail** has been lost or damaged beyond repair.

C.10.3 MAINSAIL

USE

- (1) The **sail** shall be hoisted on a halyard. The arrangement shall permit hoisting and lowering of the **sail** at sea.
- (2) The highest visible point of the **sail**, projected at 90° to the mast **spar**, shall not be set above the lower edge of the mast **upper limit mark**. The intersection of the **leech** and the top of the boom **spar**, each extended as necessary, shall not be behind the fore side of the boom **outer limit mark**.
- (3) **Luff** and **foot** bolt ropes shall be in the **spar** grooves or tracks.
- (4) The **tack** may be secured by a pin or a tack strop of optional design.

C.10.4 JIB

USE

The jib may be furled or reefed when racing.

Section D – Hull

D.1 PARTS

- D.1.1 MANDATORY
 - (a) Hull shell
 - (b) Deck
 - (c) Buoyancy Tanks
 - (d) Bulkheads
 - (e) Thwarts

D.1.2 OPTIONAL

(a) Gunwale rubbing strakes/fend off

D.2 GENERAL

D.2.1 RULES

The **hull** shall comply with the **class rules** in force at the time of initial **certification.**

D.2.2 CERTIFICATION

See Rule A.8 & A.10.

D.2.3 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) The hull shell, deck, bulkheads, buoyancy and thwarts shall not be altered in any way except as permitted by these **class rules**.
- (b) Routine maintenance such as polishing and the repair of minor scratches and abrasions is permitted without re-measurement.
- (c) If any hull moulding is repaired in any other way than described in D.2.3(b), an **official measurer** may verify on the **certificate** that the external shape is the same as before the repair and that no substantial stiffness, or other, advantage has been gained as a result of the repair. The **official measurer** shall describe the details of the repair on the **certificate**.

D.2.4 DEFINITIONS

HULL DATUM POINT

The **hull datum (HDP)** is the plane running athwartships through the aftermost point of the keel on the hull centreline.

D.2.5 IDENTIFICATION

- (a) The hull shall carry the Building Plaque permanently fixed in a conspicuous position on the hull.
- (b) The sail/serial number shall be stamped on the plaque in numbers a minimum of 3mm high.
- (c) Removal of the plaque shall invalidate the boat's certificate.

D.2.6 BUILDERS

- (a) The **hull** shall be built and completed to official specifications by a builder licensed by the Copyright Holder.
- (b) All moulds shall be approved by the Copyright Holder.
- (c) The NCA and WTC have the right to measure all moulds and tooling.

D.3 HULL SHELL

D.3.1 MATERIALS

The hull shell shall be built from GRP or foam sandwich.

D.3.2 CONSTRUCTION

- (a) Each **hull** shall comply with the official drawings for its specific design or type. The permitted designs are:
 - (i) Wanderer (pre 1990)
 - (ii) Wanderer 90
 - (iii) Wanderer MD
 - (iv) Wanderer Club
 - (v) Wanderer Esprit
 - (vi) Wanderer HB
- (b) Slot gaskets/closure strips are permitted for the **centreboard** slot.
- (c) Holes for fastenings used to attach fittings shall be a maximum of 10mm diameter. They shall be sealed to maintain the water-tightness of buoyancy compartments.

D.4 DECK

D.4.1 MATERIALS

The deck shall be built from GRP.

D.4.2 CONSTRUCTION

- (a) Foredeck, side decks, aft deck and side benches shall conform to the official plans.
- (b) A spinnaker chute shall conform to the official drawings and specifications.

D.5 BUOYANCY TANKS

D.5.1 CONSTRUCTION

Buoyancy equipment shall comprise of:

- (a) A bow and side buoyancy compartment as a single watertight unit which shall extend as far aft as the aft edge of the centre thwart.
- (b) The side buoyancy tanks may extend aft as far as the aft transverse bulkhead or for the Esprit and HB as far as the transom.
- (c) There shall be a watertight bulkhead at the aft end of each side buoyancy tank.
- (d) Positive buoyancy units of closed cell plastic foam shall be securely fixed within the hull as follows:
 - (1) One unit of not less than 30kg lift at the forward end of each compartment
 - Units providing not less than a total of 60kg lift so that no part of any unit is more than 800mm from the aft bulkhead or more than 1380mm from the transom in the Esprit and HB. The combined lift shall be approximately evenly distributed on either side of the fore and aft centreline.
- (e) The stern locker shall not be considered as a buoyancy compartment and need not be tested. However its bulkhead and decks shall be watertight and the drain holes permitted in the bulkhead and transom shall be effectively stoppered when racing. The hatch shall be fitted with a gasket and effective means of securing.
- (f) Not more than 2 drain tubes each of a maximum of 30mm dia may connect the drain holes in the aft bulkhead with those in the transom. Any such tubes shall make watertight joints with the bulkhead and transom and shall not affect the water-tightness of the stern locker. The HB and Esprit are excluded from this rule.

D.6 GUNWALE AND RUBBING STRAKES

D.6.1 MATERIALS

The rubbing strakes shall be of a resilient material.

D.6.2 CONSTRUCTION

The rubbing strake shall run unbroken on each gunwale.

D.7 BULKHEADS

D.7.1 MATERIALS

The bulkheads shall be built from GRP.

D.7.2 CONSTRUCTION

The bulkheads shall conform to the official plans.

D.8 THWARTS AND BENCHES

D.8.1 MATERIALS

Centre thwart shall be solid or laminated timber or GRP for HB and Esprit.

D.8.2 CONSTRUCTION

For HB and Esprit the thwarts and benches shall be from the official moulds and to the official specification.

D.9 ASSEMBLED HULL

D.9.1 FITTINGS

(a) MANDATORY

The following fittings shall be positioned in accordance with the official drawings:

- (1) Stemhead fitting/bow plate
- (2) Forestay fitting
- (3) Shroud plates shall be close fitting within the deck.
- (4) Headsail fairleads 1 on each side of centreline may be mounted on tracks and adjusted while racing.
- (5) Mainsheet horse or track or bridle fixed to the transom
- (6) Mast step
- (7) Keelband of corrosion resistant material shall be fitted from the underside of the stemhead to the forward end of the **centreboard** slot, on both sides of the **centreboard** slot and from the aft end of the **centreboard** slot to the transom.

(8) FLOORBOARDS Except Esprit and HB

- (a) They shall be plywood of minimum thickness 8mm.
- (b) There shall be 1 or 2 either side of the centreline.
- (c) The combined weight shall be min 7kg max 11kg
- (d) Apertures for finger holes, pump, drain and self-bailers are permitted.
- (e) They shall be substantially in accordance with the official drawings and shall not make a watertight joint with the bulkheads, centreboard case and hull.
- (f) They shall be removable but fitted when racing.
- (9) Rudder fittings
- (10) Spinnaker sheet fairleads located on the side decks

(b) OPTIONAL

- (1) Mainsail sheet blocks and centre jammer
- (2) Mainsail Cunningham blocks, fairleads and cleats (N.B. may also be fitted on mast.)
- (3) Headsail fairleads and cleats
- (4) Spinnaker sheet and guy fairleads, blocks and cleats
- (5) Spinnaker twinning lines fairleads, blocks and cleats
- (6) Spinnaker pole uphaul and downhaul fairleads, blocks and cleats
- (7) Spinnaker halyard//retrieval line fairleads, blocks and cleats.
- (8) Reinforcement pads for fittings
- (9) Stowage clips for paddle(s), spinnaker pole, sail bags and other equipment
- (10) Anchor stowage fittings

- (11) Deck clips for cockpit cover and/or tent
- (12) Mooring cleats or U Bolts and fairleads
- (13) Compass bracket
- (14) Bilge pump
- (15) Spinnaker Sock

D.9.2 DIMENSIONS

minimum maximum
Hull length excluding stem band
HDP to main forward face of aft bulkhead on centreline
25mm from upper edge (excluding HB & Esprit) 560 mm 600 mm
Beam of hull , excluding rubbing strakes and fittings, at
sheerline;
at section 586mm from HDP 1550 mm 1590 mm
at section 1700mm from HDP 1755 mm 1795 mm
at section 3120mm from HDP 1220 mm 1260 mm
Longitudinal distance around hull from hull datum point as defined in D.2.3;
to forward edge of centreboard slot
to aft edge of centreboard slot
to aft edge of centreboard bolt
Lower edge of centreboard bolt to
underside of keel excluding keelband 55 mm 75 mm
Internal width of centreboard slot at 5mm up from
underside of keel excluding keelband
Keelband:
Thickness 8 mm
Width 20 mm
Centre thwart – excluding HB & Esprit:
Width 212 mm 232 mm
Thickness 15 mm
Longitudinal distance from the outer corner of the
hull datum point as defined in D.2.4
or the hull moulding for the Esprit
or HB to centre of shroud plate attachment 2435 mm
Transverse distance between centres of shroud
attachments
Mainsheet track/horse/bridle on transom measured between
stops or attachment points; length855 mm 1285 mm
Headsail sheet fairlead: uppermost point of contact with:
Taut jib sheet above upper surface of thwart
Taut jib sheet above upper surface of thwart for HB 40 mm
Spinnaker sheet fairlead:
Forward most point of fitting from HDP 585 mm 625 mm
Bearing point of fitting from outer edge of deck65 mm 85 mm
Forward bulkhead drainage holes – max 2 - dia

Aft bulkhead drainage holes – max 2 - dia	
Longitudinal bulkhead drainage holes – max 1 - dia	
Transom drainage holes – max 4 - dia	
Esprit and HB ONLY	
Self draining apertures in transom – 2 in number: Width	
Height	
Longitudinal bulkhead openings aft of centre thwart	
One opening per bulkhead - Wanderer MD ONLY	
Length	
Height	
In Forward bulkhead 1 or 2 circular inspection ports	
diameter95 mm 125 mm	
centre from upper edge of bulkhead240 mm	
centre from centreline	
In each Longitudinal bulkhead 1 circular inspection port	
diameter95 mm 125 mm	
Hatch in aft deck (excluding Wanderer Club, Esprit and HB)	
Width of opening at forward end830 mm860 mm	
Width of opening at aft end685 mm 715 mm	
Width of opening at aft end – MD version655 mm 685 mm	
Length of opening	
Optional holes in Foredeck:	
2 holes with centres within 60mm of the mast recess –	
dia of each 10 mm	
1 hole on centreline a maximum of 270mm from	
Forward end of hull, including fittings - dia 5 mm	
Apertures in <u>each</u> side deck or structure in the horizontal and vertical surface:	
1 Rowlock socket (must be sealed & watertight	
if in a buoyancy compartment) Dia	
Aggregate area in horizontal and vertical surfaces of	
Spinnaker sheet control ports (excludes Esprit & HB) 1200 mm ²	
One hand hold – extending from the HDP (excludes Esprit & HB) 495 mm	
Length 175 mm	
Width	
Self bailers – maximum 2. Aperture in hull skin for each	
WEIGHTS	
minimum maximum	
Combined weight of floorboards	

D.9.3

Section E – Hull Appendages

E.1 PARTS

E.1.1 MANDATORY

- (a) Centreboard
- (b) Rudder
- (c) Tiller and stock

E.1.2 OPTIONAL

(a) Tiller extension

E.2 GENERAL

E.2.1 RULES

Hull appendages shall comply with the **class rules** in force at the time of **certification**.

E.2.2 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) Hull appendages shall not be altered in any way except as permitted by these class rules.
- (b) Routine maintenance such as painting, polishing and the repair of minor scratches, abrasions and edge damage is permitted without remeasurement and re-certification.

E.3 CENTREBOARD

E.3.1 MANUFACTURERS

The **centreboard** shall be made by manufacturers licensed by the copyright holder.

E.3.2 MATERIALS

The **centreboard** shall be of solid wood, marine plywood or GRP.

E.3.3 CONSTRUCTION

- (a) The **centreboard** (including any protective bands) shall conform to official drawings.
- (b) A GRP **centreboard** shall be constructed in a mould approved by the Copyright Holder.
- (c) The edges may be protected by metal or plastic strips or solid resin.
- (d) The weight may not be concentrated in any one area.

E.3.4 FITTINGS

OPTIONAL

- (1) Handles to assist raising and lowering may be fitted
- (2) A control line with cleat may be fitted to prevent retraction in case of capsize.

E.3.5 DIMENSIONS

	minimum	maximum
Thickness – uniform excluding chamfer	18 mm	28 mm
Chamfer from any edge	mm	65 mm

	Protective band thickness 10 mm
E.3.6	WEIGHTS
	minimum maximum
	Weight of complete centreboard
E.4	RUDDER BLADE, RUDDER STOCK AND TILLER
E.4.1	MANUFACTURERS
	(a) The rudder and rudder stock shall be made by manufacturers licensed by the copyright holder.
	(b) The manufacturer of the tiller and tiller extension is optional.
E.4.2	MATERIALS
	(a) The rudder blade shall be of solid wood, marine plywood or GRP.
	(b) The rudder stock shall be of aluminium.
	(c) The tiller shall be of aluminium.
	(d) The tiller extension material is optional.
E.4.3	CONSTRUCTION
	(a) The rudder blade (including any protective bands) shall conform to official drawings.
	(b) A GRP rudder blade shall be constructed in a mould approved by the Copyright Holder.
	(c) The edges may be protected by metal or plastic strips or by solid resin.
E.4.4	FITTINGS
	OPTIONAL
	(1) Uphaul and downhaul lines with blocks and cleats.
E.4.5	DIMENSIONS
	minimum maximum Thickness – uniform excluding chamfer 18 mm 28 mm
	Chamfer from any edge
	Protective band thickness
	Tiller length overall (excluding extension) 1200 mm
Soct	ion E. Dia
Seci	ion F – Rig
F.1	PARTS
F.1.1	MANDATORY
	(a) Mast
	(b) Boom
	(c) Standing rigging
	(d) Running rigging
F.1.2	OPTIONAL
	(a) Spinnaker pole
	(b) Whisker pole

F.2 GENERAL

F.2.1 RULES

- (a) The **spars** and their fittings shall comply with the **class rules** in force at the time of **certification** of the **spar**.
- (b) The standing and running **rigging** shall comply with the **class rules**.

F.2.2 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) **Spars** shall not be altered in any way except as permitted by these **class rules**.
- (b) Routine maintenance such as polishing and the replacement of defective fittings is permitted without re-measurement and re-**certification**.

F.2.3 DEFINITIONS

MAST DATUM POINT

The **mast datum point** is the **heel point**.

F.2.4 MANUFACTURER

Spars shall be manufactured under licence from the copyright holder.

F.3 MAST

F.3.1 MATERIALS AND CONSTRUCTION

- (a) The **spar** shall comply with the official plans and specifications.
- (b) The mast shall be capable of being raised and lowered on the pin inserted through the pivot hole in the **mast spar** and king posts.
- (c) The extended line of the forestay and jib luff shall meet the mast below the edge of the Rigging Band

F.3.2 FITTINGS

- (a) MANDATORY
 - (1) Mast head fitting
 - (2) Shroud points
 - (3) A set of fixed or swinging spreaders
 - (4) Mainsail halyard sheave box
 - (5) Headsail halyard sheave box
 - (6) Gooseneck
 - (7) Kicking strap attachment
 - (8) Heel fitting with not more than 5 sheaves for halyards and spinnaker uphaul.
 - (9) Mast gate chafing plates

(b) OPTIONAL

- (1) Halyard tensioner One Highfield lever or a pully system of not more than 16:1
- (2) One mechanical wind indicator
- (3) Compass bracket
- (4) Cunningham control fittings
- (5) Topping lift and fittings.
- (6) Spinnaker halyard sheave box.

	(7) Spinnaker pole fitting.
	(8) Spinnaker pole uphaul and downhaul fittings.
F.3.3	DIMENSIONS
	minimum maximum
	Mast pivot hole from Mast Datum Point
	Mast limit mark width
	Rigging band height
	Lower point to upper point
	Spinnaker hoist suspended in any direction
	from a bearing point from the Rigging band mm 80 mm
F.4	воом
F.4.1	MATERIALS AND CONSTRUCTION
	(a) The spar shall comply with the official plans and specifications.
F.4.2	FITTINGS
	(a) MANDATORY
	(1) Mainsheet block attachments
	(2) Clew outhaul blocks and attachments and cleats
	(3) Kicking strap fitting
	(4) Gooseneck attachment
	(b) OPTIONAL
	(1) Spinnaker pole stowage fittings
	(2) Slab reefing fittings
	(3) Shroud chafing plates
F.4.3	DIMENSIONS
	minimum maximum
	Boom spar overall length
	Boom point to kicking strap attachment
F.5	SPINNAKER POLE AND/OR WHISKER POLE
F.5.1	MANUFACTURER
	Manufacturer is optional.
F.5.2	MATERIALS
	The spar shall be of wood or aluminium.
F.5.3	CONSTRUCTION
	Optional
F.5.4	FITTINGS
	Fittings are optional.
F.5.5	DIMENSIONS
	minimum maximum
	Spinnaker pole length
	Whisker pole length mm 1750 mm

F.6 STANDING RIGGING

F.6.1 MATERIALS

The standing **rigging** shall be of stainless steel.

The forestay may be of rope

F.6.2 CONSTRUCTION

MANDATORY

- (1) A forestay
- (2) One pair of Shrouds

F.6.3 FITTINGS

MANDATORY

(1) One pair of Spreaders

F.7 RUNNING RIGGING

F.7.1 MATERIALS

Materials are optional.

F.7.2 CONSTRUCTION

- (a) MANDATORY
 - (1) Mainsail halyard
 - (2) Mainsail sheet
 - (3) Kicking strap
 - (4) Headsail halyard
 - (5) Headsail sheets
- (b) OPTIONAL
 - (1) Mainsail Cunningham line
 - (2) Mainsail outhaul
 - (3) Spinnaker halyard and retrieval line
 - (4) Spinnaker sheet and guy
 - (5) Spinnaker pole lift and downhaul
 - (6) Spinnaker twinning lines
 - (7) Slab reefing lines
 - (8) Jib furler or reefing line
 - (9) Centreboard retraction preventer line

Section G - Sails

G.1 PARTS

G.1.1 MANDATORY

- (a) Mainsail
- (b) Headsail

G.1.2 OPTIONAL

(a) Spinnaker

G.2 GENERAL

G.2.1 RULES

Sails shall comply with the **class rules** in force at the time of **certification**.

G.2.2 CERTIFICATION

- (a) The official measurer shall certify mainsails and headsails in the tack and spinnakers in the head and shall sign and date the certification mark. The cost of the measurer's services in respect of sails shall be met by the owner
- (b) Racing sails <u>shall</u> be measured, and at the request of the WTC, any sail <u>may</u> be required to be measured
- (c) The ISAF or an MNA may appoint one or more **In-House Official Measurers** to measure and **certify sails** produced by that manufacturer.

G.2.3 SAILMAKER

No licence is required.

G.3 MAIN SAIL

G.3.1 IDENTIFICATION

- (a) The class insignia of a stylised W in white on a dark blue disc of 500mm dia +/- 50mm shall conform to the official plans. They shall be placed back to back on both sides of the mainsail.
- (b) The sail numbers shall comply with the RRS. National letters are optional.

G.3.2 MATERIALS

- (a) The **ply** fibres shall consist of polyester of a contrasting colour to that of the Insignia background. Sails of more than one colour are permitted.
- (b) **Stiffening** shall consist of:
 - (1) Cornerboards of plastic or aluminium
 - (2) Battens of wood or GRP
- (c) **Sail reinforcement** shall consist of polyester.

G.3.3 CONSTRUCTION

- (a) The construction shall be: **soft sail**, **single ply sail**.
- (b) The **body of the sail** shall consist of the same **woven ply** throughout except within 350mm of the **foot**
- (c) The **sail** shall have a maximum of 3 batten **pockets** in the **leech**.
- (d) The centre of the batten **pockets** shall fall within +/- 70mm of the **quarter**, **half** and **three-quarter leech points**.
- (e) The following are permitted: Stitching, glues, tapes, bolt ropes, corner eyes, headboard with fixings, Cunningham eye or pulley, batten pocket patches, batten pocket elastic, batten pocket end caps, mast and boom slides, one window, tell tales, sail shape indicator stripes and items as permitted or prescribed by other applicable rules.
- (f) Optional sail head buoyancy is permitted except nothing shall be used that shall have the effect of extending the **leech**

G.3.4 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured.

minimum maximum
Leech length
Quarter width
Half width
Three-quarter width 1010 mm
Top width
Primary reinforcement
Distance from clew point to foot bolt rope
Distance from tack point to foot bolt rope
Sail head buoyancy patch from head point
Window contained in a rectangle
Window to sail edge150 mm
Extension of headboard from head point
Batten pocket length:
uppermost pocket:
inside 675 mm
lower pockets:
inside 800 mm
Batten pocket width:
inside

G.4 HEAD SAIL

G.4.1 MATERIALS

- (a) The **ply** fibres shall consist of Polyester
- (b) Sail reinforcement shall consist of Polyester

G.4.2 CONSTRUCTION

- (a) The construction shall be: **soft sail**, **single ply sail**.
- (b) The **body of the sail** shall consist of the same **woven ply** throughout.
- (d) The **leech** shall not extend beyond a straight line from the aft **head point** to the **clew point**.
- (e) The following are permitted: Stitching, glues, tapes, corner eyes, hanks, one **window**, tell tales, sail shape indicator stripes and items as permitted or prescribed by other applicable *rules*.

G.4.3 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured.

	minimum	maximum
Luff length		4025 mm
Leech length		3780 mm
Foot length		2090 mm
Foot median		3860 mm
Top width		45 mm

Primary reinforcement	410 mm
Window contained in a rectangle	
Window to sail edge	150 mm

G.5 SPINNAKER

G.5.1 IDENTIFICATION

The sail numbers shall comply with the RRS. National letters are optional.

G.5.2 MATERIALS

- (a) The **ply** fibres shall consist of Nylon or Polyester.
- (b) Sail reinforcement shall consist of Polyester

G.5.3 CONSTRUCTION

- (a) The construction shall be: **soft sail**, **single ply sail**.
- (b) The **body of the sail** shall consist of the same **woven ply** throughout.
- (c) The following are permitted: Stitching, glues, tapes, corner eyes, recovery line, tell tales and items as permitted or prescribed by other applicable *rules*.

G.5.4 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured.

	minimum	maximum
Leech lengths	mm	4430 mm
Foot length	mm	2950 mm
Foot Median	mm	4600 mm
Difference between diagonals		50 mm
Half width	mm	2890 mm
Three-quarter width	mm	1670
Primary reinforcement		410 mm
Secondary reinforcement : for recovery line point	•••••••••••	260 mm

PART III – APPENDICES

The rules in Part III are **closed class rules**. Measurement shall be carried out in accordance with the ERS except where varied in this Part.

Section H – Appendix 1

H.1 BUOYANCY TESTS

H1.1 RESPONSIBILITY FOR BUOYANCY TESTS/INSPECTIONS.

Buoyancy tests and inspections shall be carried out in accordance with rules in section H. The builder shall carry out a dry buoyancy test before delivery to the owner, and this shall be recorded on the Builder's Certificate. After the acquisition of a boat, responsibility for buoyancy testing rests with the owner. The owner is advised to carry out a buoyancy inspection every 12 months, and a buoyancy test at intervals of not more than 3 years.

H1.2 DRY BUOYANCY TEST. SHALL BE CONDUCTED AS FOLLOWS:

- a) Hatches shall be closed normally, using only the boat's own hatch covers.
- b) Drainage holes from the buoyancy compartment shall be closed with their normal stoppers, except where tubes to a pressure/vacuum source and gauge are connected.
- c) Equipment for producing and assessing pressure differentials between the buoyancy compartment and surrounding atmosphere, and including a suitable manometer, shall be connected to the compartment.
- d) Super-atmospheric or sub-atmospheric pressure shall be applied to the compartment, sufficient to produce a differential reading of at least 120 mm water gauge pressure.
- e) After isolating the buoyancy compartment from the vacuum or pressure source, the pressure differential specified in d above shall not reduce from 120 mm to 50 mm in less than 30 seconds.

H1.3 WET BUOYANCY TEST. SHALL BE CONDUCTED AS FOLLOWS:

- a) Buoyancy compartment joints, hatch gaskets & hatch fasteners. Shall be inspected by the buoyancy tester for efficiency
- b) Hatches shall be closed normally, using only the boat's own hatch covers and fasteners
- c) Drainage holes from buoyancy compartments shall be closed with their normal stoppers.
- d) The boat shall be floated on its beam ends with the masthead touching the water .A load of at least 115kg (235 lbs) shall be applied vertically to the hull (the weight of two persons can conveniently provide this load). After a minimum of 5 minutes in this condition with one gunwale submerged, the test shall be repeated for a minimum of 5 minutes with the other gunwale submerged.
- e) The boat shall be floated upright in a waterlogged condition immediately after the test in d It shall remain in this condition for a minimum of 10 minutes, then be emptied.

f) The buoyancy compartments shall be inspected for significant leakage immediately after completion of the test. There shall be no more than 4.5 litres (1 gallon) in the bow buoyancy compartment.

H1.4 DRY BUOYANCY TESTING IS PREFERRED TO WET BUOYANCY TESTS.

H1.5 BUOYANCY INSPECTION.

It is recommended that buoyancy inspections should be carried out as follows. The owner should carefully check the condition of watertight joins to ensure that they are in good condition. The owner should be satisfied that hatches, sealing rings and drain hole stoppers are all in good condition, and that no significant amount of water has entered any buoyancy compartment.

Change History

Date	Change
2010	Final pre ERS version
1/3/2012	Adopted the ERS standard
1/3/2014	Corrected Spinnaker dimensions
3/3/2018	Allowed HB Foam Sandwich racing Wanderer, Jib reefing and multicolour sails
3/3/2019	Temporary dispensation for twin spinnaker poles added

Previous issues: 2010, 2012, 2014, 2018

© Wanderer Class Owners' Association